







①	Leitung	Cable	<b>JP43717</b>
②	Stator + Gehäuse	Stator + Housing	<b>JP47042</b>
③	Rotorwelle	Rotor shaft	<b>JP45791</b>
④	Motorabdichtung	Motor seals	<b>JP46806</b>
⑤	Laufadschraube	Impeller screw	<b>JP46802</b>
⑥	Lagersatz	Bearing set	<b>JP46724</b>
⑦	Lagerschild	Bearing housing	<b>JP43720</b>
⑧	Dichtungssatz	Seal set	<b>JP46807</b>
⑨	Laufad	Impeller	
	10/4		<b>JP45793</b>
	15/4		<b>JP45794</b>
	25/4		<b>JP45795</b>
⑩	Schraubensatz	Screw set	<b>JP47291</b>

# JUNG PU



①	Leitung	Cable	<b>JP43717</b>
②	Stator + Gehäuse	Stator + Housing	<b>JP44008</b>
			25/2
			35/2
③	Rotorwelle	Rotor shaft	<b>JP47038</b>
			35/2
④	Gleitringdichtung	Mechanical seal	<b>JP46567</b>
⑤	Laufschraube	Impeller screw	<b>JP46805</b>
⑥	Lagersatz	Bearing set	<b>JP46214</b>
		Bearing housing	<b>JP43726</b>
		Seal set	<b>JP46807</b>
		Impeller	<b>JP46715</b>